

# RS232 to RS485 / RS422 Converter



## Jumper Setting

JP1	CLOSE		RS485 / RS-422 Transmit Termination ON 120 Ohm
JP1	OPEN	Default	RS485 / RS-422 Transmit Termination OFF
JP2	CLOSE		RS-422 Receive Termination ON 120 Ohm
JP2	OPEN	Default	RS-422 Receive Termination OFF 120 Ohm
JP4	CLOSE 1-2		RS-232 TXD to DB9M Pin 3
JP4	CLOSE 2-3	Default	RS-232 TXD to DB9M Pin 2
JP5	CLOSE 1-2		RS-232 RXD to DB9M Pin 2
JP5	CLOSE 2-3	Default	RS-232 RXD to DB9M Pin 3
JP6	CLOSE 1-2		Enable RS-485
JP6	CLOSE 2-3	Default	Enable RS-422
JP7	CLOSE 1-2		Enable RS-485
JP7	CLOSE 2-3	Default	Enable RS-422

JP4 and JP5 physically connect the proper RXD or TXD to the pins of the RS-232 connector. Therefore removing from all shorting bars of either jumper will eliminate any connection to that pin.

The default jumper selection allows for RS-422 operation. Data from the TXD RS-232 port is continuously sent out the RS-422 TXD pins. Data is continuously recieved from the RS-422 RXD pins to the RXD RS-232 port.


When selected for RS-485 operation the RTS pin of the RS-232 side is used to control the flow of data. Therefore when RTS is High data is recieved to the RXD RS-232 port from the RS-485 and when RTS is Low data is transmitted out the RS-485 from the TXD RS-232 port.

## DB9M Pin Out

1	N/C
2	RXD/TXD
3	RXD/TXD
4	DTR True
5	GND
6	N/C
7	RTS
8	N/C
9	12VDC Input

## Default

TXD  
RXD



## Ground

- RS422T (+) / A)
- RS422T (-) / B)
- RS422R (+) / A) / RS485+ (A)
- RS422R (-) / B) / RS485- (B)

Pin 9 can be 12VDC input to power the adapter. However no voltage is output from this pin when the external power supply is used.

## Connecting the VSI-Pro to the RS-485 Port of the MVDR3000 or MVDR5000

JP1 Close, JP2 Open, JP4 None, JP5 Close 2-3, JP6 2-3, JP7 None

## MVDR3000 / 5000 RS-232 to RS-422/485 Adapter

RJ12 - 6 Pin Modular Screw Terminals

- 1 --- N/C
- 2 --- GND ----- GND ---- Terminal 5
- 3 --- V+ ----- A+ ----- Terminal 1
- 4 --- V- ----- B- ----- Terminal 2
- 5 --- GND ---- N/C
- 6 --- N/C