

HDD Viewer

The HDD Viewer is a tool that lets you playback and archive the video data on the hard disk from DVR(Digital Video Recorder). By using HDD viewer, you can easily search the video for a critical moment and export the images or video to standard Jpeg/ AVI format as important evidence.

Before you start using the HDD viewer, please connect the hard disk to a PC either through the USB external cable or the IDE cable .



HDD Viewer

HDD Viewer Ver.2.38

The screenshot shows the HDD Viewer software interface. On the left is a video playback window showing a road scene with a license plate that reads "PROSECUT" and "9:34:07". Below the video are playback controls, including a "PAUSE" button and a set of navigation buttons (stop, play, previous, next, first, last) which are highlighted with a red box. On the right is a "File Mode" / "Disk Mode" panel. It shows "DISK 1 - 80GB" and a list of recording entries. The list has columns for "Start Time" and "End Time". Below the list is a search bar with a date dropdown set to "11/22/2009" and a time dropdown set to "09:34:43". A search icon is also present. Three callout boxes provide instructions: one points to the list, another to the search bar, and a third to the navigation buttons.

File entry list show the list of the record along with record type select box

Time search for search the video by enter time and date that need to see.

click mode

| | Start Time | End Time |
|---|---------------------|---------------------|
| 1 | 03/24/2009 13:17:50 | 11/19/2008 12:44:29 |
| 2 | 11/19/2008 15:09:51 | 11/19/2008 15:22:03 |
| 3 | 11/19/2008 15:22:35 | 11/19/2008 15:50:59 |
| 4 | 11/20/2008 07:09:43 | 11/20/2008 07:33:37 |
| 5 | 11/20/2008 09:29:15 | 11/20/2008 10:29:31 |
| 6 | 11/21/2008 11:57:39 | 11/21/2008 12:16:13 |
| | 12/08/2008 07:53:07 | 11/24/2008 08:36:13 |
| | 08 14:26:48 | 11/25/2008 15:04:51 |
| | 08 06:25:20 | 12/01/2008 07:47:39 |
| | 08 07:47:39 | 12/01/2008 08:02:50 |
| | 08 08:28:26 | 12/03/2008 08:53:15 |
| | 08 08:53:46 | 12/03/2008 10:05:06 |
| | 08 11:59:52 | 12/04/2008 12:10:19 |
| | 08 06:28:37 | 12/08/2008 06:56:27 |

HDD Viewer

Export

Start: 12/17/2008 11:04:45 Set

End: 12/17/2008 11:05:44 Set



File Format : AVI JPG

Resolution : Low High

Directory Path: C:\Program Files\HDDViewe

File Name : Driving_19low .avi

Progress : Processing... 20%

Cancel Exit

Time

- 12:44:29
- 15:22:03
- 15:50:59
- 07:33:37
- 10:29:31
- 12:16:13
- 08:36:13
- 15:04:51
- 07:47:39
- 08:02:50
- 08:53:15
- 10:05:06
- 12:10:19
- 06:56:27


HDD Viewer

Open the vault door by the key.



HDD Viewer

Turn off the HDD mobile rack key and pull out the HDD rack .



HDD Viewer

Put the HDD rack into the USB removeable mobile rack and connect to the USB port of PC or labtop that install HDD Viewer after that run the HDD Viewer program.

